

KLEAR-SCREENS

Request to Quote



Company: _____

Address: _____

City: _____ State: _____ Zip: _____

Contact Name: _____

Phone: _____ Fax: _____

E-mail: _____

MIDWESTERN INDUSTRIES, INC.

midwesternind.com
Toll Free: 877-474-9464
P.O. Box 810
Massillon, OH
44648-0810
Fax: (330) 837-4210

Southern Facility
7560 Industrial Hwy
Macon, GA 31216
Fax: (478) 781-8746

PANEL MEASURING GUIDE

If possible, measure the screener box and location of the support bars to ensure the KLEAR-SCREEN will fit into the unit and properly align with the support bars.

In cases where measuring the screener box and the support bars inside of the box is not possible, follow these steps to measure the screen panel:

STEP 1: Measure the panel from the outside of one hook to the outside of the hook on the opposite end of the panel. (Make sure the panel is flat)

STEP 2: Measure the length of the hook. (Note the hook type)


STEP 3: Measure from the outside of one hook to the center of the screen panel. (In most cases there will be a polyurethane strip in the center or there will be two strips equal distance from the centerline)

STEP 4: Measure from the centerline of the panel to the center of each strip. (It is important to measure from the centerline of the panel to the center of each strip to avoid compiling error)


STEP 5: Measure the wire size and opening of the screen panel. (See the diagram on back for opening measurements and types)

Please fill out boxes below.


"Style" (S,M,W,H)	
Opening Size	
Wire Size and Type	
Hook Type	
1" Lap or Edging	




"S" STYLE



"M" STYLE




"W" STYLE



"H" STYLE


Measure the length of each screen panel section as indicated by the arrows in the diagram below. Enter the corresponding measurements into the bracketed areas shown in the diagram below.



1" POLYURETHANE LAP (SIDE TENSION)




EPDM EDGING (END TENSION)



DETAIL A-A POWER HOOK



DETAIL A-A TYPE 2 HOOK



DETAIL A-A TYPE 5 HOOK

DETAIL A-A